


ES EXPLOSIÓN  
UNIDAD EXTERIOR BC 22-27 MAX

PT EXPLOÇÃO  
UNIDADE EXTERIOR BC 22-27 MAX

GB BLOW-U  
OUTDOOR UNIT BC 22-27 MAX

**BAXI**




ES EXPLOSIÓN  
UNIDAD EXTERIOR BC 22-27 MAX

PT EXPLOÇÃO  
UNIDADE EXTERIOR BC 22-27 MAX

GB BLOW-U  
OUTDOOR UNIT BC 22-27 MAX

**BAXI**




ES EXPLOSIÓN UNIDAD INTERIOR BC 22-27 MAX

PT EXPLOÇÃO UNIDADE INTERIOR BC 22-27 MAX

GB BLOW-UP INDOOR UNIT BC 22-27 MAX

**BAXI**




ES EXPLOSIÓN HIDRÁULICA  
UNIDAD INTERIOR BC 22-27

PT EXPLOÇÃO HIDRÁULICA  
UNIDADE INTERIOR BC 8

GB HYDRAULIC BLOW-UP  
INDOOR UNIT BC 22-27

**BAXI**



ES CUADRO CONTROL BC 22-27

PT QUADRO DE CONTROLE BC 22-27

GB CONTROL PANEL BC 22-27

**BAXI**

